

Dongguan Daly Electronics Co. Ltd

Product Specifications

Product Model: DL-R32U-F08S80ATJ-MM00-S4RV

Product Name: LiFePO4 8S 24V80A Common port with Balance, UART, Bluetooth

Version: Rev 1.0 – Modified to Solar 4 RV's Specifications



Product Summary:

- Using foreign premium IC class-A protection.
- Professional, high-current wiring design and workmanship thus can withstand the shock of high current
- Using heat-dissipating glue with a double-sided heat dissipation design, heat is dissipated passively
- Physically shock-resistant, waterproof PCB with many protective functions
- Complete over-charge, over-discharge, over-current, short-circuit, and equalization functions

Electrical Parameters: (Room temperature 25 °C, humidity 55%)

(N0)		(Specification)	(Unit)	Remarks	
1	(Discharge)	(Continuous discharge current)	80	A	
2	(Chargo)	(Charge voltage)	29.2	V	Adjustable
2	(Charge)	(Continuous charge current)	80	A	
3 (Over charge protection)	(Over charge detect voltage)	3.7±0.05	V	Adjustable	
	protection)	(over charge protection delay)	1	S	Adjustable

SOLAR
4 RVs

늗						
			(over charge release voltage)	3.6±0.05	V	Adjustable
			(Balance detect Voltage)	3.20	V	Adjustable
	4	(Balance)	(Balance release voltage)	3.20	V	Adjustable
			(Balance current)	30±5	mA	
į			(Over discharge detect)	2.6±0.1	V	Adjustable
	5	(Over discharge)	(Over discharge detect delay)	1	S	Adjustable
		protection	(Over discharge release voltage)	2.7±0.1	V	Adjustable
			(Overcharge current detect)	240±40	A	Adjustable
ŀ	6 (Over Charge current protection)		(Overcharge current detect delay)	1	S	Adjustable
			(Overcharge current protection release condition)	(Off load)		
			Over discharge current detect	300±50	A	Adjustable
	7	(Over discharge current protection)	(Over discharge current detect delay)	1	S	Adjustable
		procession	(Over discharge current protection release condition)	(Off load)		
	8	(Short Circuit	(Short Circuit protection condition)	(Short circuit of external load)		
			(Short circuit detect delay)	320	μS	Adjustable
			(Short circuit protection release)	(Off load)		
	9	(Temp	(Charge Temperature	-5~55	°C	Adjustable
			protection degrees)			
	,	Protect)	(discharge Temperature protection -30~60 °C		Adjustable	
			degrees)			


DL-R32U-F08S80ATJ-MM	100-C1DV
DE KOZU PUCOCUALI MIM	MAN SAIV

SOLAR
4 RVs

10	(Means of communication)	UART (Adjusting Settings) PC Interface Bluetooth (Status Only) Android and iOS		BMS	Play Store/ App Store: SMART BMS DalyBMS
11	(Inner Resistance)	(Main Circuit Conduct Inner resistance)	<20	mΩ	
12	Self	(Working current)	15	mA	
	Consumption	Sleep current (over-discharge)	600	uA	
13	(Working Temp)	(Temp range)	-20~70	$^{\circ}$	
13	(Storing Temp)	(Temp range)	-40~80	$^{\circ}$ C	

(BMS wiring Connection)


(1) (Product picture)





(Interface definition)


B00 B01 B02 B14 B15 B16 GND OW_3.3V	1 2 3 15 16 17 1	Battery Total Negative Battery positive electrode 1 Battery positive electrode 2 Battery positive electrode 14 Battery positive electrode 15 Battery positive electrode 16 GND	
B02 B14 B15 B16 GND	3 15 16 17	Battery positive electrode 1 Battery positive electrode 2 Battery positive electrode 14 Battery positive electrode 15 Battery positive electrode 16	
B02 B14 B15 B16 GND	3 15 16 17	Battery positive electrode 2 Battery positive electrode 14 Battery positive electrode 15 Battery positive electrode 16	
B14 B15 B16 GND	15 16 17	Battery positive electrode 14 Battery positive electrode 15 Battery positive electrode 16	
B14 B15 B16 GND	15 16 17 1	Battery positive electrode 14 Battery positive electrode 15 Battery positive electrode 16	
B15 B16 GND	16 17 1	Battery positive electrode 15 Battery positive electrode 16	
B16 GND	17	Battery positive electrode 16	
GND	1		
		GND	
OW_3.3V		3110	
	2	Bluetooth module power supply 3.3 V	
15V	3	Power supply 15 V GPS module	
BLU_DRV	4	Tower supply 13 v di 3 inicuale	
		GPS control of power outages/recovery	
JRAT_TX	5		
2		Bluetooth communication Transmitter	
JRAT_RX 2	6	Bluetooth communication Receiver	
TRIG+	1	Activate input pin	
TD16		Metivate input pin	
TRIG-	2	Activate output pin	
GND	1	1 1	
		GND	
OW_3.3V	2	227/61	
C 1	2	3.5 V of lamp board power supply	
31	S	Keyboard	
LED_51	4	-	
LED_41	5		
LED_31	6		
J. J	TRIG- GND DW_3.3V S1 LED_51 LED_41	15V 3 LU_DRV 4 RAT_TX 5 2 RAT_RX 6 2 TRIG+ 1 TRIG- 2 GND 1 DW_3.3V 2 S1 3 LED_51 4 LED_41 5	Bluetooth module power supply 3.3 V 15V 3 Power supply 15 V GPS module LU_DRV 4 GPS control of power outages/recovery RAT_TX 5 2 Bluetooth communication Transmitter RAT_RX 6 2 Bluetooth communication Receiver TRIG+ 1 Activate input pin TRIG- 2 Activate output pin GND 1 GND 1 GND 0 OW_3.3V 2 3.3 V of lamp board power supply S1 3 Keyboard LED_51 4 Fifth lamp (100%) LED_41 5 Fourth lamp (80%)







	LED_21	7	
	222_21	,	Second Lamp (40%)
	LED_11	8	
	_		First Lamp (20%)
	NTC1	1	
Temperature			Temperature Line #1
sensor input	GND	2	G) ID
port	> T =		GND
	NTC2	3	T
	NTCE	1	Temperature Line #2
Temperature	NTC5	1	Temperature Line #3
sensor input	GND	2	Temperature Line #3
port	GND	2	GND
Post	NTC4	3	
			Temperature Line #4
	LIADE DV	1	
	UART_RX 1		485 Communication receiver
485 /			
CAN	UART_TX	2	
communicatio n interface	1		485 Communication transmitter
II IIIICITACC	GND	3	GND
	CAN_H	4	GND
	0111_11		CAN communication high
	CAN_L	5	
	_		CAN communication low
	AI1	1	
	All	1	Switching signal
Reserved IO	AI2	2	
interface	1 112		Switching signal
	DI1	3	
			Switching signal
	DO1	4	Carried in a 1
			Switching signal
	VCC_EX	5	External power supply
			External power suppry
	GND_EX	6	External power supply
			Entertial power suppris











(Warranty)

We guarantee a 3-year product warranty, if the damage is caused by improper operation, we will conduct the repair with charge. The warranty does not cover shipping costs, the cost of shipping both to and from the user must be paid for by the user.

(Additional Information)

- 1. Lithium battery BMS units with different voltage ranges cannot be mixed. i.e. The LiFePO4 BMS cannot be used for LiPo batteries.
- 2. Daly uses high quality cables, do not replace the Daly provided cables with any other cables.
- 3. When testing, installing, or contacting the protective board, take measures to avoid static electricity.
- 4. Do not let the heat dissipation surface of the protection board directly contact the battery core, otherwise the heat will be transmitted to the battery core, which will affect the safety of the battery.
- 5. Do not disassemble or change the components of the protection board.
- 6. The metal heat sink of the protection board is anodized and insulated, and the oxide layer will still be conductive after being destroyed. Avoid contact between the heat sink and the battery core and the nickel strip.
- 7. If you believe you are experiencing any abnormal operation, discontinue use until verified ok by Daly.
- 8. Do not use the two Daly BMS units in series.
- 9. Two or more units can be used in parallel if each unit is capable of sustaining the maximum load current.
- 10. Every product is tested by Daly engineers before shipping.